
Bubble Machine



1byone Products Inc.
1230 E Belmont Street, Ontario, CA, USA 91761
Customer Service: +1 909-391-3888
www.1byonebros.com

Made in China

Instruction Manual

Introduction

Thank you for purchasing 1byone Bubble Machine. This instruction manual contains important information about safety, usage, and disposal. Use the product as described and keep this manual for future reference. If you sell this bubble machine or pass it on, also give this manual to the new owner.


Safety Instructions

- This product is only authorized for domestic use and not for commercial or industrial purposes. It is only intended for applications described in these instructions.
- Children or dependents should not use, clean, or perform maintenance on the bubble machine without adult supervision.
- Only connect the bubble machine to a power outlet type as indicated in the "Specifications" section of this manual.
- To completely disconnect from power, remove the batteries and unplug the power adapter.
- Make sure the power cable is visible at all times to avoid stepping on or tripping over it.
- The machine should not be exposed to dripping or splashing water. If moisture, water, or any liquid gets inside the housing, immediately unplug from power and contact a qualified technician to check and repair it.
- Do not open the housing of the bubble machine. There are no user-serviceable parts.
- Never leave the machine unattended when it is switched on or connected to power.
- Never aim the bubble machine at open flames.
- Do not aim the bubble machine directly at people as bubble liquid may leave permanent markings on clothing.
- Do not transport with liquid. If the machine gets wet, do not use until it is completely dry.
- Always keep batteries out of the reach of infants and young children to prevent the batteries from being swallowed. If swallowed, take immediate action and contact medical authorities for help.

1 by one

Product Description

1. DC-IN Jack
2. Liquid Level Display
3. Reservoir
4. Bubble Wand
5. ON/OFF/Speed Switch
6. Handle
7. Battery Compartment



Included Items

1 x Bubble Machine
1 x Power Adapter
1 x Instruction Manual

Before using the bubble machine for the first time, check the package contents to ensure all parts are free of visible damage.

Inserting Batteries (Optional)

To insert the batteries, unscrew the screw on the battery compartment on the top of the machine and remove the compartment cover. Insert 6 C batteries (not included), paying attention to the correct polarity.

Operating Instructions

1. Place the bubble machine on a solid, flat surface and in a well-ventilated area.
2. Pour bubble liquid into the liquid reservoir. Always ensure the liquid level immerses at least one wand. Do not fill the reservoir over the noted maximum level.
3. If batteries have not been installed, plug the bubble machine into a grounded electrical outlet. If batteries are installed and the machine is also connected to an outlet, then outlet power will be used.

IMPORTANT: When using the bubble machine powered by batteries, remove the power adapter from the bubble machine or it won't work.

4. Turn the ON/OFF/Speed Switch clockwise to Speed Level 1.
5. Turn the Switch again for Speed Level 2.

Attention:
It is normal for the bubble machine to produce less bubbles when using battery power than when plugged in with the power adapter.

Note:
- Keep the air intake ports free from blockage.
- Do not use outdoors in the rain as this may lead to a short circuit.
- Do not leave unused liquid in the reservoir for an extended period. The liquid may thicken in the reservoir. Remove all liquid before storing or moving.
- If the bubble machine is to be mounted using a bracket, please note the machine should only be inclined to a maximum angle of 15 degrees.
- The bubble machine should not be used for more than 8 hours consecutively and is best operated at 40º-90ºF (4º-32ºC). Performance of the machine may be reduced in low temperatures.

Cleaning

1. Empty all bubble liquid from the machine.
2. Rinse and drain the reservoir using a little distilled water.
3. Add some warm distilled water to the maximum level.
4. After adding water, turn on the bubble machine and allow it to run in a well-ventilated area until all wands appear to be free of residue.
5. Drain the remaining water to complete cleaning.

Note:
- It is recommend to clean the bubble machine after every 40 hours of operation.
- Do not spin the fan using compressed air to avoid damage.
- Always remove the power adapter from the socket before refilling the liquid or cleaning the bubble machine.

1 by one

Storage

- If you do not intend to use the bubble machine immediately, it is best to unplug the power cord from the power socket, or remove the batteries.
- Once the machine has been disconnected from power, it is recommended to empty the reservoir and store the machine in a dust-free and dry place.

Specifications

Model: 1-SP03US01,LT-148
AC Adapter Voltage: 100-240V~50-60Hz
Rated Power: 13.5W
Batteries: 6 x C batteries
Output: 9V ⎓ 1.5A
Size: 170(L)x210(W)x170(H)mm/6.69x8.27x6.69in
Weight: 1.04kg/2.29lbs
Max Tank Capacity: 380ml/13oz

The appliance's packaging is made from environmentally friendly material and can be disposed of at your local recycling plant.

Customer Service/Kundenservice
Service Clients/Atención al cliente/Assistenza Clienti

UNITED STATES	Phone: +1 909-391-3888 (Mon-Fri 9:00am - 5:00pm PST) Email: ushelp@1byonebros.com
CANADA	Email: cahelp@1byonebros.com
UNITED KINGDOM	Phone: +44 158 241 2681 (Mon-Fri 9:00am - 6:00pm UTC) Email: ukhelp@1byonebros.com
GERMANY/FRANCE ITALY/SPAIN	Email: euhelp@1byonebros.com

BRAND OWNER

1byone Products Inc.
1230 E Belmont Street, Ontario, CA, USA 91761
Customer Service: +1 909-391-3888
www.1byonebros.com

1 by one